



200 Universal Dr. • Owosso • MI 48867
989-725-8354 • Fax 989-725-8409
1-800-433-3604



Installation Kit No. LIK-22 (107)

Contents: (2) Plastic Push Pins

INSTALLATION INSTRUCTIONS

Step 1: Remove the Tailgate screws located in the center of metal Truck Tailgate. (Save the screws)

Step 2: Place plastic Tailgate cover onto metal Truck Tailgate and align the holes.

Step 3: Insert the original Tailgate screws saved in step 1; do NOT tighten.

Step 4: Locate the Side “TABS” of the tailgate cover, fold it down along side of metal tailgate.

Step 5: Insert plastic push pin into holes in the tab and the holes located on the sides of metal tailgate (See diagram below).

Step 6: Finish tightening the center screws; Do not over tighten to avoid damage on the screw threads.

