



---

200 Universal Dr. • Owosso • MI 48867

989-725-8354 • Fax 989-725-8409

1-800-433-3604



**Installation Kit No. LIK-C2 (102)**

Contents: (2) 2 – 20mm Torx Screws

# TAILGATE INSTALLATION

**Step 1:** Remove the manufacturer's bolt/screws which correspond with the pre-drilled holes in your plastic Tailgate cover. (Discard the bolts/screws)

**Step 2:** Place the plastic Tailgate cover onto metal truck tailgate and align the pre-drilled holes.

**Step 3:** Install the bolts/screws provided, through the pre-drilled holes in the tailgate cover, and the holes in the metal truck tailgate. **Do not Tighten**

**Step 4:**

- For 1988-98 Full Size Chevrolet / GMC models: follow instructions provided in the installation kit LIK-1.

**Step 5:** Tighten bolts/ screws from section 3 securely.

