





Kit 1597

VOLKSWAGEN Jetta, 4-dr Sedan, 05–
VOLKSWAGEN GLI, 4-dr Sedan, *08–
*North America



Kit






1




2



+





3




754

1




2




X

| | |
|-----------------------------------|------|
| VOLKSWAGEN Jetta, 4-dr Sedan, 05- | 38,5 |
| VOLKSWAGEN GLI, 4-dr Sedan, *08- | 38,5 |

1




2



Y


| | |
|-----------------------------------|----|
| VOLKSWAGEN Jetta, 4-dr Sedan, 05- | 35 |
| VOLKSWAGEN GLI, 4-dr Sedan, *08- | 35 |




480R

480

1




2




X inch **X mm**

| | | |
|-----------------------------------|----------------------------------|---------|
| VOLKSWAGEN Jetta, 4-dr Sedan, 05- | 40 ³ / ₄ " | 1036 mm |
| VOLKSWAGEN GLI, 4-dr Sedan, *08- | 40 ³ / ₄ " | 1036 mm |

1




2



Y inch **Y mm**

| | | |
|-----------------------------------|----------------------------------|---------|
| VOLKSWAGEN Jetta, 4-dr Sedan, 05- | 39 ³ / ₈ " | 1001 mm |
| VOLKSWAGEN GLI, 4-dr Sedan, *08- | 39 ³ / ₈ " | 1001 mm |

4



480R/754



480

VOLKSWAGEN Jetta, 4-dr Sedan, 05-
VOLKSWAGEN GLI, 4-dr Sedan, *08-

164



1087



163



1087



137








714



137





714



5



| | X mm | Y mm | X inch | Y inch |
|-----------------------------------|--------|--------|---------|---------|
| VOLKSWAGEN Jetta, 4-dr Sedan, 05- | 320 mm | 725 mm | 12 5/8" | 28 1/4" |
| VOLKSWAGEN GLI, 4-dr Sedan, *08- | 320 mm | 725 mm | 12 5/8" | 28 1/4" |



GB/US Tighten alternately

D Die Schrauben abwechselnd anziehen

F Serrer alternativement chaque côté

NL Afwisselend aan de linker- en de rechterkant aandraaien

I Alternare il serraggio delle viti

E Serrare alternativamente

PT Aperte alternadamente

S Dra åt växelvis

FIN Kierrä vuorotellen

EST Pinguldage vaheldumisi

LAT Pielieciet pamišus

LIT Užsukinėkite pakaitomis

PL Śruby dokręcaj naprzemiennie

RU Затягивайте попеременно

CZ Pokręťta bagażníka dokręcaj dokręcaj naprzemiennie.

SK Doťahujte striedavo

SLO Privijajte izmenično.

HR Naizmjenično zategnite

HU Egymástól függetlenül szorítandó

GR Σφιγγετε εναλλάξ

TR Dönüşümlü sıkın


中文 交替拧紧

한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันโนแบบสลับ





6




480R/754




480





7




x1
17 mm





THULE
SWEDEN
**ONE
KEY
SYSTEM**



- 544** (x4)
- 596** (x6)
- 588** (x8)
- NA **510** (x10)
- EUR **452** (x12)
- ASIA

